

CF Test Spray

Product Information



Field of application	Test spray for identifying areas on CF or CFB sheets printed with desensitising ink.
Product composition	Test spray, spray can, propellant.
Product description	Preparation of acetone and a crystal violet-lactone derivative.
Toxicological and dermatological safety	The mixture is not classified in acute oral toxicity. Wash off immediately with water. If skin irritation persists, consult a doctor. Repeated contact can lead to rough or cracked skin. Causes serious eye irritation. May cause drowsiness and dizziness.
Environmental hazards	Soluble in water, evaporates from aqueous solution. Low toxicity to aquatic life. Easily biodegradable. The product should not be allowed to enter drains, watercourses or the soil.
Storage and handling	Ensure good ventilation or air extraction at the workplace. Avoid aerosol formation. Ensure good room ventilation also in the floor area (vapours are heavier than air). Keep away from sources of ignition – no smoking. Protect from heat. Take measures against electrical charging. Filled aerosol dispensers must not be exposed to heating of more than 50 ° C from sunlight. Observe laws and regulations for the storage and use of flammable substances.
Fire hazard	Extremely flammable aerosol. Pressurized container: may burst if heated.
Disposal	The product must be disposed of in compliance with the respective local, regional, national or international regulations. Must not be disposed of with household waste. Do not empty into drains.
First aid measures	Call a doctor immediately. Remove contaminated clothing immediately. After inhalation: supply fresh air, if affected consult a doctor. After skin contact: wash off immediately with water. Consult a doctor if skin irritation persists. After eye contact: remove contact lenses if possible. Rinse eyes with open eyelids for several minutes under running water and consult a doctor. After swallowing: rinse mouth. Do not induce vomiting, seek medical attention immediately. Aspiration hazard. Keep airways clear.

In case of further questions please contact our Technical Service:

> technical.service.mpe@mitsubishi-paper.com